



AURORA™ LIGHT FIXTURE For the Cogent Training Headwall

www.hospitalystems.com



Installation Instructions

READ THROUGH THESE INSTRUCTIONS COMPLETELY PRIOR TO ATTEMPTING ANY INSTALLATION

Room finishing should be completed and a junction box with appropriate wiring to the correct circuit should be installed at the proper fixture location before installing the Aurora™ light fixture

Tel: 925.427.7800
Fax: 925.427.0800

support@hospitalystems.com

Hospital Systems Inc.
750 Garcia Avenue
Pittsburg CA 94565
USA

1. Remove the lower lens by unscrewing the two lens screws



Remove the mounting plate shipped attached to the Aurora™ Light at the back of the fixture with two safety nuts located inside the lower lamp cavity.





www.hospitalystems.com

Installation Instructions

Tel: 925.427.7800
Fax: 925.427.0800

support@hospitalystems.com

Hospital Systems Inc.
750 Garcia Avenue
Pittsburg CA 94565
USA

©2006 HSI

In the end of the fixture are slotted louvers. Determine which end of the fixture will be against the Cogent Training Headwall and carefully knock out at least one of the webs. This will allow passage of the wire feed for the fixture



Mount the back plate to the building wall. NOTE: This mounting plate must be level and completely tight against the building wall, and must not be bent or bowed.



Position the fixture so that it rests in the top groove of the mounting plate. Lower the fixture and align it on the safety screws.





www.hospitalystems.com

Installation Instructions

Tel: 925.427.7800
Fax: 925.427.0800

support@hospitalystems.com

Hospital Systems Inc.
750 Garcia Avenue
Pittsburg CA 94565
USA

©2006 HSI

Re-install the safety nuts. Use of any other nut may allow the fixture to fall.



Remove the back plate that is exposed in the lower lamp compartment. This will expose the ballasts and internal wiring. Feed the wire through the hole you have made when you removed the web at the end of the fixture and fed the wire into the Cogent Training Headwall. Attach these wires with those in the Cogent Training Headwall marked for the light fixture. Replace the back plate

Install the appropriate lamps (not included)
! Be sure to insert the lamps properly. Loose lamps will cause the socket to overheat!
Replace the lenses and screws.





www.hospitalystems.com

Installation Instructions

Tel: 925.427.7800
Fax: 925.427.0800

support@hospitalystems.com

Hospital Systems Inc.
750 Garcia Avenue
Pittsburg CA 94565
USA

©2006 HSI

Install the lenses:
The lower lens is inserted into the upper groove, and while holding it in position in the upper groove, insert the two screws. Note that the screws do NOT go through the lens but along its edge.
The upper lens is hooked into one side and then squeezed slightly to fit the opposite side. Upon releasing the lens, it will snap into position.

If you have any questions regarding any of the above, please contact your local representative, or the factory direct at 925.427.7800

